

Email: sales@secureakat.com.au

Web: www.secureakat.com.au

Phone: 0424 754 052

DIY Component Info

- 1. TOTAL SIZE OF NET REQUIRED, TO CUT YOUR PIECES FROM, PLUS 100mm EXTRA FOR CUTTING. (like cutting a pattern from fabric)
- 2. WIRE AS REQUIRED ONE LENGTH FOR EACH STRAIGHT EDGE (or can go round corners on shorter runs)
- 3. CLIPS (S HOOKS) AS REQUIRED approx 3 PER 1 METRE PLUS 1 EXTRA PER WIRE & ALLOW SOME SPARES. (For all edges attached to walls, fences or floors.)
- 4. TECH SCREWS AND CONCRETE SCREWS AS REQUIRED (to secure clips to walls, fences or floors.)
- 5. TURNBUCKLES AS REQUIRED ONE FOR EACH WIRE (OVER 4Mtr – 5mm T/BUCKLE. UNDER 4Mtr – 4mm T/BUCKLE.)
- 6. SWAGES 2 FOR EACH WIRE (Swage tool required)
- 7. WIRE ROPE GRIPS 2 FOR EACH WIRE (instead of swages)
- 8. TWINE 6 METRES PER ZIP (supplied with zips)

Recommended order of build:

- 1. Install s-hooks at each end and down the length of each wire to be fitted at the recommended spacing.
- 2. Make up wires and fit them loosely where they will be when the structure is complete.
- 3. Hang net over structure on the hooks and trim to size
- 4. Thread the pre made wires through the meshes of the net and tighten the turnbuckles to secure/tension.
- 5. Install zips and/or gates/doors and seal all corners and other gaps with cord or twine.



Email: sales@secureakat.com.au Web: www.secureakat.com.au Phone: 0424 754 052 Call us today for feline freedom at friendly prices Australia-wide


Email: sales@secureakat.com.au

Web: www.secureakat.com.au

Phone: 0424 754 052

EXAMPLE ONLY


Netting – 1 Piece



On one end of each wire make a loop and use a wire rope grip. Put a turnbuckle and wire rope grip on the other end.

Screws and 'S' Hooks need to be placed 3 to every metre plus an extra for the end of each wire (a few extra have been supplied).

Wires – each colour is a different wire





Email: sales@secureakat.com.au Web: www.secureakat.com.au Phone: 0424 754 052